






## Pneumatic control classification

code	description	schema	dimensions	configuration
F020A	Pneumatic control ON - OFF	-> GVV[B0A]-		
F021A	Pneumatic control ON - OFF rotated 180°	-> GVV[B0A]-		
F022A	Proportional Pneumatic control			Proportional control with port BSP: G 1/8
F023A	Proportional Pneumatic control rotated 180°	-> GVV[B0A]-		
F135A	Pneumatic control ON - OFF	-> GVV[B0A]-		
F136A	Pneumatic control ON - OFF rotated 180°	-> GVV[B0A]-		
F126A	Proportional Pneumatic control	-> GVV[B0A]-		Proportional control with port NPTF: 1/8-27
F127A	Proportional Pneumatic control rotated 180°	-> GVV[B0A]-		

## Proportional pneumatic control curve

The diagram shows the spool stroke as a function of the pneumatic pressure operating.

